

BLACK & WHITE DANCE FLOOR

Black Dance Floor Includes: Full Panels 4' x 2', Half Panels 2' x 2', Edging
White Dance Floor Includes: Full Panels 4' x 2', Half Panels 2' x 2', Edging



INSTRUCTIONS

STEP 1

Row #1: Lay the first FULL panel at the top left-hand corner of the floor with the three END LUGS pointing to the left and lay the second FULL panel alongside the first with the END LUGS pointing to the right. The first two panels sit next to each other. Now lay the third and the rest of the top row FULL panels with the END LUGS pointing to the right with the bare side of the panel sitting on top of the previous panel's END LUGS.

STEP 2

Fit the edging pieces across the top row, starting from the left-hand side with a HALF edge and the a FULL edge which will span the joint of the first two FULL panels. Continue fitting the FULL edging pieces while using a HALF edge at the end of the row to fit flush with the right-hand side.

STEP 3

Row #2: The second row starts with a HALF panel again on the left-hand side. As with the first row, the END LUGS will point to the left. Now complete the row with FULL panels ending with a HALF panel, lugs pointing right.

STEP 4

Row #3: Lay the third row like the first row with FULL panels.

STEP 5

Row #4: Lay the fourth row like the second row, starting and ending with a HALF panel.

STEP 6

Following Rows: Continue laying the floor in this fashion until the desired floor size is achieved.

Edging

To complete the dance floor, lay the edging last. Start at the top right-hand side with a right-hand edge piece followed by a FULL edge. Continue down the right-hand side of the floor, ending with a left-hand corner edge.

AFTER HOURS:

Contact your local branch.



NOTE

Never move the trolley without the removable top bar fitted.