

# VINTAGE OAK & FLORLOK DANCE FLOOR

Vintage Oak Includes: Full Panels 3' x 3', Half Panels 3' x 11/2", Edging

Florlok Includes: Full Panels 3' x 3', Half Panels 3' x 11/2", Edging



## INSTRUCTIONS

---

### STEP 1

**Row #1:** To lay the floor, start at the top left corner. Position the panels to all face the same way.

### STEP 2

Place the second panel to the right of the first, facing in the same direction as the first, with the 3 end lugs pointing to the right.

### STEP 3

**Fit the panels together:** Hold the second panel at an angle, and push it so the lugs slide underneath the panel previously laid. When the lugs are fully under and both panels are completely touching along their edges, lower the panel to the floor. If the panels are not square or the edges do not touch, the panel will not lower. **DO NOT FORCE** the panel down. Adjust it until it lowers into position.

### STEP 4

Continue to lay the first row with as many full panels as required for the size of the floor (a completed row of 3 panels = 9' floor). Position panels flush along the entire length of the row to ensure a straight edge. **Tip:** Stand on the pieces that are already set.

### STEP 5

**Row #2:** Begin with a half panel with the 3 end lugs pointing to the right. Follow with full panels as in Row #1. End the row with a half panel.

### Edging:

After Row #2 is complete, lay the edging. The edging acts as a straight edge to ensure each row is square and flush as it is laid. Attach the edging by pushing the lugs underneath the panels at an angle and lowering to the floor in the same manner as the panels. **DO NOT FORCE** the fit. Half-length and full-length edges are supplied so that the panel and edging joints never coincide, following an overlapping brickwork pattern. The angled pieces always position on the corners of the floor, as shown, never on a straight side.

### Remaining Rows:

Use full panels for Row #3 and start and finish with half panels for Row #4. Continue alternating rows with full and half panels, fitting edging until full dimension of floor is laid.

### AFTER HOURS:

Contact your local branch.

---



### NOTE

Never move the trolley without the removable top bar fitted.

Store the flooring in a well-ventilated area, never in a hot, dry environment.

Avoid excessive exposure to moisture.