EBONY + WINSTON BARS



INSTRUCTIONS

STEP 1

Open the 2 sides of the base.

TOP



STEP 2

Take bag of screws that are attached to the back of the bar. Align bar top holes with screws and tighten in place.



consistently delivering^{tn}

EVENT SOURCE EventSource.com 877.901.0000

PANACHE EVENTS PanacheEvents.com

800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 173-300 Ebony Bar SKU 173-200 Winston Bar