

# 10-16' ADJUSTABLE BACKDROP



## INSTRUCTIONS

### STEP 1

Place base plate on ground with peg pointing up. Then insert solid side of upright onto peg.

### STEP 2


Place next base plate desired length away 6', 8', or 10' feet away and insert upright onto peg the same as before.

### STEP 3

Adjust crossbar to desired length of 6', 8', or 10' foot. Place drape on crossbar using the sewn pocket of the bottom of the drape. Slip crossbar through the pocket so drape is secured to crossbar. Repeat with for a total of 4 or 5 drapes per crossbar, depending on height.

### STEP 4

Next, insert hook end of crossbar into slot on top of upright. Attach opposite end into the second upright previously set up. Repeat this process for as many runs as desired. Finally, raise the uprights by lifting up on the upper end of upright until you reach your desired height of between 10-16 feet high.



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

**SKU 425-3700 10-16' Starter**  
**425-3800 10-16' Add On**



#### NOTE

Please note ladders may be needed to safely set up backdrop.