

PROPANE HOTCUBE INSULATED CABINET



INSTRUCTIONS

STEP 1

Connect tank to propane hose located on the back of the unit in the bottom left corner. Turn valve on propane tank to “**ON**” position.

STEP 2

Turn thermostat knob (located on the back of unit in the top right corner) to **10**.

STEP 3

Open door at the base of unit by turning the door handle counter-clockwise. This is where the gas valve dial is located.

STEP 4

Turn gas valve dial to “**PILOT**” position.

STEP 5

Depress and hold gas valve dial, allow pilot to burn approximately 30 seconds before releasing the gas valve dial. If pilot does not remain lit, repeat operation allowing longer time period before releasing gas valve dial.

STEP 6

The unit is now operating. When heat is desired, turn gas valve dial to “**ON**” position. When heat is no longer required, turn the gas valve dial back to “**PILOT**” position.

STEP 7

When the unit is in the “**ON**” position adjust the thermostat to desired setting. When the thermostat is set to “**1**” the unit will hold at approximately 140° F. Set to “**10**” the unit will hold at approximately 200° F.

STEP 8

To turn unit off, turn the gas valve dial to “**PILOT**” first. While the gas valve dial is still depressed, turn the gas valve dial to “**OFF**” position. Once the pilot light has diminished, disconnect the propane tank.



EVENT SOURCE
PANACHE EVENTS

consistently delivering™

EVENT SOURCE
EventSource.com
877.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU CR-2400 INCLUDES

Eleven sets of pan slide positions can hold 11 - 18 x 26” Bun pans or 22 - 12 x 20” pans (not included).



NOTE

The maximum size sterno is 2.75”H by 3.5”W.