

LED LIGHTS + REMOTE

INSTRUCTIONS

STEP 1

Sync lighting unit with remote.

STEP 2

Switch on back of light from Charge to **ON**.

STEP 3

Press and hold (around 2 seconds) white PGM button until it goes from red to orange/yellow. Lighting unit is now available to be connected to a remote.

STEP 4

Switch on top of remote from **OFF** to **ON**. The display on remote should light up.

STEP 5

Remote is now connected to lighting unit. Multiple lights can be connected to a single remote and placed on separate frequencies and set to different colors..

STEP 6

Set color of lighting unit.

- Use UP/DN COLOR buttons to achieve the desired color.
- DO NOT USE** UP/DN MASTER buttons.
- Remote button color list and numbers are as follows:

	RED	GREEN	BLUE	ORANGE	WHITE
White	0	0	0	0	100
Red	100	0	0	0	0
Orange	0	0	0	100	0
Yellow	30	40	0	100	0
Green	0	100	0	0	0
Blue	0	0	100	0	0
Purple	70	0	100	0	0
Pink	100	0	20	0	0

- Once color is set press Black Out (located bottom right hand corner of remote)
- Turn off remote
- DO NOT TURN OFF LIGHTING UNIT.** If turned off, you will have to start from step 1.

STEP 7

Start of event

- Turn remote **ON**, set desired color using UP/DN buttons on remote.
- Turn **OFF** remote.



consistently delivering™

EVENT SOURCE

EventSource.com

877.901.0000

PANACHE EVENTS

PanacheEvents.com

800.30.PARTY (72789)

SO COOL EVENTS

SoCoolEvents.com

305.635.8088

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU

DL5-2550 LED Lights

SC-7100 Light Remote Control



VIDEO LINK

<https://vimeo.com/761895094/fc4163dbc9>



NOTE

6-8 hours of run time per unit.