

# FISH COOKER/ PROPANE BURNER



## INSTRUCTIONS

### STEP 1

Connect propane tank and open valve.

### STEP 2

Slightly open valve on Fish Cooker/Propane Burner.

### STEP 3

Light burner using EXTREME CAUTION.

### STEP 4

Adjust air intake for blue flame.



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

#### SKU 302-900 INCLUDES

Open Valve

#### OPTIONS

20lb propane tank  
40lb propane tank  
grill hood



#### NOTE

It is recommended that you use a long grill lighter to avoid contact with hands.

Always use in a well-ventilated area.

OUTDOORS IS PREFERRED!

#### PROPANE USE



Tank = 20lb, 40lb



20lb @ 6hrs, 40lb @ 11hrs