

10-16' ADJUSTABLE BACKDROP



INSTRUCTIONS

STEP 1

Place base plate on ground with peg pointing up. Insert solid side of upright onto peg.

STEP 2

Place next base plate desired length away 6, 8, or 10 feet away and insert upright onto peg the same as before.

STEP 3

Adjust crossbar to desired length of 6, 8, or 10 feet. Place drape on crossbar using the sewn pocket at the bottom of the drape. Slip crossbar through the pocket so drape is secured to crossbar. Repeat with 3 more pieces of drape for a total of 4 drapes per crossbar.

STEP 4

Insert hook end of crossbar into slot on top of upright. Attach opposite end into the second upright previously set up. Repeat this process for as many runs as desired.

AFTER HOURS:

Contact your local branch.



NOTE

Please note ladders may be needed to safely set up backdrop.