

# ELECTRIC STEAM TABLE

Includes: 3 Wells, 3x 2" Deep Full Food Pans & Lids, 10' Extension Cord



## INSTRUCTIONS

---

### STEP 1

Fill each well to the **FILL** line inside of the well (approx. 4 qt). Do not overfill.

### STEP 2

Plug the power cord into **GROUNDING 120V** outlet.

### STEP 3

Turn the power switch to the **ON** position.

### STEP 4

Cover wells with **LIDS FOR FULL FOOD PANS** and set temperature knob on each well to the highest setting to preheat. Let stand for approximately 20-30 min.

### STEP 5

Place hot food pans into wells.

### STEP 6

Set heat control to the desired setting.

### AFTER HOURS:

Contact your local branch.

---



### WARNING

**DO NOT** overfill the wells to avoid water overflowing when food is placed in pans.