

EVO GRILL COOK TOP

Includes: Hood, Cook Top, 1 Drip Pan



INSTRUCTIONS

STEP 1

Be sure that all regulator valves are in the **OFF** position.

STEP 2

Remove hood and cook top.

STEP 3

Remove labeled lower bar and secure propane tank in bottom fitting.

STEP 4

Connect hose to propane tank. Tighten counter-clockwise and open the valve.

STEP 5

Locate **IGNITION** button beneath the regulator valve panel.

STEP 6

Turn regulator valves to **LITE** position.

STEP 7

Press **IGNITION** button until the pilot bars ignite.

STEP 8

Replace cook top.

STEP 9

Turn regulator valves to desired setting.

AFTER HOURS:

Contact your local branch.



NOTE

This unit can **ONLY** use a 20lb propane tank.

PROPANE USE

A 20lb propane tank will last on the Evo Grill Cook Top for approximately 2-3 hours.