

LED LIGHTS & REMOTE



INSTRUCTIONS

STEP 1

Sync lighting unit with remote using steps 2-4.

STEP 2

Using the switch on the back of the light, turn from CHARGE to **ON**.

STEP 3

Press and hold (around 2 seconds) the white PGM button until it goes from red to orange/yellow. The lighting unit is now available to be connected to a remote.

STEP 4

Using the switch on top of the remote, switch from **OFF** to **ON**. The display on the remote should light up.

STEP 5

The remote is now connected to the lighting unit. Multiple lights can be connected to a single remote and placed on separate frequencies and set to different colors.

STEP 6

To set the color of the lighting unit:

- Use UP/DN COLOR buttons to achieve the desired color.
- DO NOT USE** UP/DN MASTER buttons.
- Remote button color list and numbers are as follows:

	RED	GREEN	BLUE	ORANGE	WHITE
White	0	0	0	0	100
Red	100	0	0	0	0
Orange	0	0	0	100	0
Yellow	30	40	0	100	0
Green	0	100	0	0	0
Blue	0	0	100	0	0
Purple	70	0	100	0	0
Pink	100	0	20	0	0

- Once color is set, press Black Out (bottom right of remote)
- Turn off remote.
- DO NOT TURN OFF LIGHTING UNIT.** If turned off, you will have to restart from step 1.

STEP 7 - Start of Event

- Turn remote ON, set the desired color using UP/DN buttons on the remote.
- Turn **OFF** remote.

AFTER HOURS:

Contact your local branch.



NOTE

6-8 hours of run time per unit.