

NACHO CHEESE DISPENSER

Options: Nacho Cheese Bags, Nacho Cheese Trays, Nacho Chips, Prepackaged



INSTRUCTIONS

STEP 1

Plug the machine into a 120V electrical outlet.

STEP 2

Preheat the dispenser for about an hour.

STEP 3

Preheat the nacho cheese bag to about 140°F.

STEP 4

Open the door by pulling from the left to right. Place the cheese bag on the tray with the spout and the tube directed downward.

STEP 5

Open the tube by turning the cam counterclockwise.

STEP 6

Guide the tube through the pump slot from the top to bottom.

STEP 7

Close the clamp by rotating the cam clockwise.

STEP 8

Close the door and cut the remaining tube ¼" below the door with clean, sanitized scissors. The tip of the tube should be visible and extend outside of the dispenser.

STEP 9

Depress the button to begin operation.

To dispense cheese:

Hold food under dispensing tube. Press dispensing button until desired amount of cheese has been dispensed.

Removing the cheese bag:

Open the door by pulling from the left to the right. Open the tube clamp by rotating the cam counterclockwise. Remove the tube from the pump from the pump slot by grabbing the tube from the lower end and raising it upward toward the tray. Remove the tubing and the bag by continuing to raise the tube upward until it is clear from the tray. Remove the empty bag and the tubing from the oven. Do **NOT** attempt to carry or lift the bag by the end of the tube.

AFTER HOURS:

Contact your local branch.
