

# POPCORN MACHINE

Includes: Machine, Scoop, Kettle, 2 Hinged Doors, Cone Holders, Drip Trays  
Optional: Cart, Popcorn, Popcorn Bags, Paper Cones



## INSTRUCTIONS

---

### STEP 1

Turn all switches to the **ON** position.

### STEP 2

Allow the empty kettle to heat for 2-3 minutes.

### STEP 3

Insert the butter package and allow the butter to melt.

### STEP 4

Add popcorn kernels and close the lid on the kettle.

### STEP 5

When popping your final serving of popcorn—as kernels begin to pop—turn the kettle heat **OFF**.

### AFTER HOURS:

Contact your local branch.

---



### WARNING

Do not immerse kettle in water during cleaning!

### NOTE

Keep the doors open while popping the popcorn.

Pop one bag at a time to avoid burning the kernels.

**One packet of popcorn will serve 10 cones or 30 bags.**