

PROPANE HOT CUBE INSULATED CABINET

Includes: 8 Bun Pans



INSTRUCTIONS

STEP 1

Connect tank to propane hose located on the back of the unit in the bottom left corner. Turn valve on propane tank to the **ON** position.

STEP 2

Turn thermostat knob (located on the back of the unit in the top right corner) to **10**.

STEP 3

Open the door at the base of the unit by turning the door handle counterclockwise. This is where the gas valve dial is located.

STEP 4

Turn the gas valve dial to **PILOT** position.

STEP 5

Depress and hold the gas valve dial and allow pilot to urn for approximately 30 seconds before releasing. If pilot does not remain lit, repeat operation, allowing more time before releasing the gas valve dial.

STEP 6

The unit is now operating. When heat is needed, turn the gas valve dial to **ON** position. When heat is no longer needed, turn the gas valve dial back to the **PILOT** position.

STEP 7

When the unit is in the ON position, adjust the thermostat to the desired setting. When the thermostat is set to 1, the unit will hold at approximately 140°F. When set to 10, the unit will hold at approximately 200°F.

STEP 8

To turn the unit off, turn the gas valve dial to **PILOT** first. While the gas valve dial is still depressed, turn the gas valve dial to the **OFF** position. Once the pilot light has diminished, disconnect the propane tank.

AFTER HOURS:

Contact your local branch.
