

PUNCH FOUNTAIN



INSTRUCTIONS

STEP 1

Cool beverage before filling. When the fountain is running, the pump will slightly warm the liquid over time. We recommend freezing an ice ring or juice cubes to keep the beverage cold.

STEP 2

Fill the fountain with 5 gallons of your beverage.

STEP 3

Plug the machine into an outlet to start the pump.

AFTER HOURS:

Contact your local branch.



WARNING

Do not immerse the base of the fountain in water during cleaning!

NOTE

To prevent clogging, use a pulp-free beverage.

Refill the fountain often. Do not let the fountain dry.

Operating capacity may fail if the fountain is not used on a compatible outlet.