

# WHITE OAK & MAPLE DANCE DECK

White Oak Dance Deck Includes: Full Panels 3' x 3', Edging

Maple Dance Deck Includes: Full Panels 3' x 3', Edging



## INSTRUCTIONS

---

### STEP 1

Begin the installation by laying down your first panel in any one corner and pointing the male dance deck in the two directions that additional panels are to be added.

### STEP 2

Place the next panel so the female dance deck lines up over the top of the male loops on the first panel. It's important to make sure that all female and male dance deck pieces are facing the same direction as the first panel throughout the entire installation.

### STEP 3

Gently step along the joint of the two panels. You will hear and feel the dance deck snap into place as you go.

### STEP 4

Once the two panels are joined, repeat steps 1 through 3, ensuring the dance deck is aligned until the entire floor is complete.

### Edging

After your dance floor is completely set, start to lay the edging. The male edging will lay under the female dance floor pieces. The female edging will lay on top of the male edging pieces. Gently step along the joint of the edge panels. You will hear and feel them snap into place as you go.

### AFTER HOURS:

Contact your local branch.

---



### NOTE

Avoid excessive exposure to moisture.