

SOUP KETTLE



INSTRUCTIONS

STEP 1

Add 20 ounces (2.5 cups) of water between the stainless steel food insert pan and the aluminum kettle insert.

STEP 2

Prepare soup to manufacturer's instructions and place into the food insert.

STEP 3

Turn the heat switch to 0; plug the cord into a 120V AC outlet and rotate the heat switch to 12 to rapidly heat product.

STEP 4

To hold and serve preheated product, set the heat switch between 1 and 6.

STEP 5

Adjust the heat switch between 1 and 6 to maintain the desired temperature. If product boils, set the heat switch to 1 until the desired temperature is reached.

STEP 6

When finished using the kettle, turn the heat switch to 0 before unplugging.



EVENT SOURCE
PANACHE EVENTS

consistently delivering™

EVENT SOURCE
EventSource.com
877.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 327-3000 INCLUDES
Insert Pan



WARNING

Never move or carry the entire kettle when it is HOT or FULL.

Never immerse the kettle in water.