

SPIRAL FLAME PATIO HEATER



INSTRUCTIONS

STEP 1

Hook up propane

- Connect the hose to the propane tank and make sure that the connection is secure
- Open the valve on the propane tank

STEP 2

Light the pilot light

- Press and turn the knob 90° counterclockwise so the arrow on the knob lines up with the red dot labeled "PILOT"
- Press and hold the knob for 45-60 seconds before pressing the ignitor
- Continue pressing and holding the knob press the red ignitor button to light the pilot light
 - If it does not light continue to press and hold the knob as there is not yet enough pressure for the pilot to light
- If the pilot lights continue to press and hold the knob for 10 seconds before letting it go

STEP 3

Heater ignition

- If the pilot is lit turn the knob counterclockwise to the desired intensity



EVENT SOURCE



PANACHE EVENTS

consistently delivering™

EVENT SOURCE

EventSource.com

877.901.0000

PANACHE EVENTS

PanacheEvents.com

800.30.PARTY (72789)

SO COOL EVENTS

SoCoolEvents.com

305.635.8088

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU

604-4300 Spiral Flame Patio Heater



VIDEO LINK

<https://vimeo.com/783425734>